



## Error codes GYTR ECU 2018/19

Christian Unger

YART GmbH

[workshop@yart7.com](mailto:workshop@yart7.com)

<b>CODE</b>	<b>DESCRIPTION</b>
<b>P0916</b>	Gear Shift Position Circuit Low
<b>P0917</b>	Gear Shift Position Circuit High
<b>P0340</b>	Camshaft Position Sensor "A" Circuit Bank 1 or Single Sensor
<b>P0335</b>	Crankshaft Position Sensor "A" Circuit
<b>P0107</b>	Manifold Absolute Pressure/Barometric Pressure Sensor Circuit Low
<b>P0108</b>	Manifold Absolute Pressure/Barometric Pressure Sensor Circuit High
<b>P0122</b>	Throttle/Pedal Position Sensor/Switch "A" Circuit Low
<b>P0123</b>	Throttle/Pedal Position Sensor/Switch "A" Circuit High
<b>P0222</b>	Throttle/Pedal Position Sensor/Switch "B" Circuit Low
<b>P0223</b>	Throttle/Pedal Position Sensor/Switch "B" Circuit High
<b>P2135</b>	Throttle/Pedal Position Sensor/Switch "A" / "B" Voltage Correlation
<b>P0069</b>	Manifold Absolute Pressure - Barometric Pressure Correlation
<b>P1004</b>	Manifold Absolute Pressure - Cylinder Identification MAP Correlation
<b>P0117</b>	Engine Coolant Temperature Sensor 1 Circuit Low
<b>P0118</b>	Engine Coolant Temperature Sensor 1 Circuit High
<b>P0112</b>	Intake Air Temperature Sensor 1 Circuit Low Bank 1
<b>P0113</b>	Intake Air Temperature Sensor 1 Circuit High Bank 1
<b>P2228</b>	Barometric Pressure Sensor "A" Circuit Low
<b>P2229</b>	Barometric Pressure Sensor "A" Circuit High
<b>P0351</b>	Ignition Coil "A" Primary Control Circuit/Open
<b>P0352</b>	Ignition Coil "B" Primary Control Circuit/Open
<b>P0353</b>	Ignition Coil "C" Primary Control Circuit/Open
<b>P0354</b>	Ignition Coil "D" Primary Control Circuit/Open
<b>P0201</b>	Cylinder 1 Injector "A" Circuit
<b>P0500</b>	Vehicle Speed Sensor "A" Circuit
<b>P0657</b>	Actuator Supply Voltage "A" circuit/Open
<b>P062F</b>	Internal Control Module EEPROM Error
<b>P1602</b>	Internal Control Module Shutoff Circuit
<b>P0560</b>	System Voltage
<b>P0601</b>	Internal Control Module Memory Checksum Error
<b>P0606</b>	Control Module Processor
<b>P2122</b>	Throttle/Pedal Position Sensor/Switch "D" Circuit Low
<b>P2123</b>	Throttle/Pedal Position Sensor/Switch "D" Circuit High
<b>P2127</b>	Throttle/Pedal Position Sensor/Switch "E" Circuit Low
<b>P2128</b>	Throttle/Pedal Position Sensor/Switch "E" Circuit High
<b>P2138</b>	Throttle/Pedal Position Sensor/Switch "D" / "E" Voltage Correlation
<b>P0638</b>	Throttle Actuator Control Range/Performance Bank 1
<b>P2158</b>	Vehicle Speed Sensor "B" Circuit
<b>P1E70</b>	YDT event
<b>C0520</b>	Multi-axis Acceleration Sensor Module "A"
<b>U0125</b>	Lost Communication With Multi-axis Acceleration Sensor Module