



Error codes GYTR ECU 2020

Christian Unger

YART GmbH

workshop@yart7.com

CODE	DESCRIPTION
C0520	Multi-axis Acceleration Sensor Module "A"
C1000	Steering Damper Solenoid Control Circuit
P0030	HO2S Heater Control Circuit Bank 1 Sensor 1
P0050	HO2S Heater Control Circuit Bank 2 Sensor 1
P00D1	HO2S Heater Control Circuit Range/Performance Bank 1 Sensor 1
P00D3	HO2S Heater Control Circuit Range/Performance Bank 2 Sensor 1
P0069	Manifold Absolute Pressure - Barometric Pressure Correlation
P0105	Manifold Absolute Pressure/Barometric Pressure Sensor Circuit
P0106	Manifold Absolute Pressure/Barometric Pressure Sensor Circuit Range/Performance
P0107	Manifold Absolute Pressure/Barometric Pressure Sensor Circuit Low
P0108	Manifold Absolute Pressure/Barometric Pressure Sensor Circuit High
P0110	Intake Air Temperature Sensor 1 Circuit Bank 1
P0111	Intake Air Temperature Sensor 1 Circuit Range/ Performance Bank 1
P0112	Intake Air Temperature Sensor 1 Circuit Low Bank 1
P0113	Intake Air Temperature Sensor 1 Circuit High Bank 1
P0115	Engine Coolant Temperature Sensor 1 Circuit
P0116	Engine Coolant Temperature Sensor 1 Circuit Range/ Performance
P0117	Engine Coolant Temperature Sensor 1 Circuit Low
P0118	Engine Coolant Temperature Sensor 1 Circuit High
P0122	Throttle/Pedal Position Sensor/Switch "A" Circuit Low
P0123	Throttle/Pedal Position Sensor/Switch "A" Circuit High
P0132	O2 Sensor Circuit High Voltage Bank 1 Sensor 1
P0133	O2 Sensor Circuit Slow Response Bank 1 Sensor 1
P0134	O2 Sensor Circuit No Activity Detected Bank 1 Sensor 1
P0152	O2 Sensor Circuit High Voltage Bank 2 Sensor 1
P0153	O2 Sensor Circuit Slow Response Bank 1 Sensor 1
P0154	O2 Sensor Circuit No Activity Detected Bank 1 Sensor 1
P0201	Cylinder 1 Injector "A" Circuit
P0202	Cylinder 2 Injector "A" Circuit
P0203	Cylinder 3 Injector "A" Circuit
P0204	Cylinder 4 Injector "A" Circuit
P0222	Throttle/Pedal Position Sensor/Switch "B" Circuit Low
P0223	Throttle/Pedal Position Sensor/Switch "B" Circuit High
P0300	Random/Multiple Cylinder Misfire Detected
P0301	Cylinder 1 Misfire Detected
P0302	Cylinder 2 Misfire Detected
P0303	Cylinder 3 Misfire Detected
P0304	Cylinder 4 Misfire Detected
P0335	Crankshaft Position Sensor "A" Circuit
P0340	Camshaft Position Sensor "A" Circuit Bank 1 or Single Sensor
P0342	Camshaft Position Sensor "A" Circuit Low Bank 1 or Single Sensor
P0343	Camshaft Position Sensor "A" Circuit High Bank 1 or Single Sensor
P0351	Ignition Coil "A" Primary Control Circuit/Open
P0352	Ignition Coil "B" Primary Control Circuit/Open
P0353	Ignition Coil "C" Primary Control Circuit/Open

P0354	Ignition Coil "D" Primary Control Circuit/Open
P0475	Exhaust Pressure Control Valve "A"
P0476	Exhaust Pressure Control Valve "A" Range/Performance
P0480	Fan 1 Control Circuit
P048B	Exhaust Pressure Control Valve "A" Position Sensor/Switch Circuit
P048C	Exhaust Pressure Control Valve "A" Position Sensor/Switch Circuit Range/Performance
P048D	Exhaust Pressure Control Valve "A" Position Sensor/Switch Circuit Low
P048E	Exhaust Pressure Control Valve "A" Position Sensor/Switch Circuit High
P0500	Vehicle Speed Sensor "A" Circuit
P0560	System Voltage
P0563	System Voltage High
P0601	Internal Control Module Memory Checksum Error
P0606	Control Module Processor
P062F	Internal Control Module EEPROM Error
P0638	Throttle Actuator Control Range/Performance Bank 1
P0657	Actuator Supply Voltage "A" Circuit/Open
P0914	Gear Shift Position Circuit
P0915	Gear Shift Position Circuit Range/Performance
P0916	Gear Shift Position Circuit Low
P0917	Gear Shift Position Circuit High
P1400	Secondary Air Induction System Control Solenoid Circuit
P1500	VSS - NGS - CES Correlation
P1600	Lean Angle Sensor Circuit / Open
P1601	Side Stand Switch Circuit
P1602	Internal Control Module Shutoff Circuit
P1806	Shift Sensor "A" Circuit Low
P1807	Shift Pedal Position "A" Circuit High
P2122	Throttle/Pedal Position Sensor/Switch "D" Circuit Low
P2123	Throttle/Pedal Position Sensor/Switch "D" Circuit High
P2127	Throttle/Pedal Position Sensor/Switch "E" Circuit Low
P2128	Throttle/Pedal Position Sensor/Switch "E" Circuit High
P2135	Throttle/Pedal Position Sensor/Switch "A"/"B" Voltage Correlation
P2138	Throttle/Pedal Position Sensor/Switch "D"/"E" Voltage Correlation
P2158	Vehicle Speed Sensor "B" Circuit
P2195	O2 Sensor Signal Biased/Stuck Lean Bank 1 Sensor 1
P2197	O2 Sensor Signal Biased/Stuck Lean Bank 2 Sensor 1
P21CF	Cylinder 1 injector "B" circuit/open
P21D0	Cylinder 2 injector "B" circuit/open
P21D1	Cylinder 3 injector "B" circuit/open
P21D2	Cylinder 4 injector "B" circuit/open
P2228	Barometric Pressure Sensor "A" Circuit Low
P2229	Barometric Pressure Sensor "A" Circuit High
U0125	Lost Communication With Multi-axis Acceleration Sensor Module
U0155	Lost Communication With Instrument Panel Cluster (IPC) Control Module